CS30-MIPI Module Product Specification

| Date | Version | Description |
|------------------|---------|-------------|
| December 3, 2023 | V0.1 | First Draft |

Contents

| 1、 | Module Description | 1 |
|----|----------------------------|----|
| 2、 | Technical Parameters | 2 |
| 3、 | Storage Conditions | 3 |
| 4、 | Module Cleaning Procedures | 3 |
| 5、 | Disclaimer | 4 |
| Ap | pendix 1: Module Drawings | .1 |

1. Module Description

Product Description:

The CS30-MIPI module consists of RX component with a resolution of 640*480 and TX component operating in the 940nm wavelength, equipped with a ToF image sensor. Utilizing ToF technology, the module excels in capturing threedimensional information about objects and spaces, showcasing remarkable features such as long-range capability and low power consumption. Additionally, the module employs a standard MIPI-CSI2 interface for the output of RAW data.

Product Features:

- Full resolution (1280 x 960) with up to 60 frames per second of raw data.
- MIPI-CSI2 standard interface: 2 lanes (1.6 Gbps per lane).
- Output formats: RAW10, RAW12.

- Camera Control Interface (CCI) and I2C compatible, two-wire serial communication circuit up to 1MHz.

2、Technical Parameters

| Technical Parameters | | | | | |
|-----------------------|--|--|--|--|--|
| Resolution | 640*480/320*240 | | | | |
| FOV | H100°xV75° | | | | |
| Measure Distance | 0.1-5m, indoor | | | | |
| VCSEL Wavelength | 940nm | | | | |
| Accuracy | 0.1~0.5m: ±2.5cm; 0.5~5m: ±1% @ 90% reflectivity | | | | |
| Dimensions | Appendix 1 2D drawing | | | | |
| Date Transmission | RAW10 | | | | |
| Powering Method | IOVDD_ToF(1.8V), VCSEL_3V3, VCC_3V3 | | | | |
| Power Consumption | TBD | | | | |
| Operating System | Android, Windows, Linux, ROS | | | | |
| Operating Temperature | -10 ~ 50°C | | | | |
| Safety | Laser CLASS1 | | | | |

3、Storage Conditions

| Conditions | Description | Min | Мах | Unit | |
|--------------------------|-------------|--------------------------|-----|------|--|
| Storage | | -15 | 60 | °C | |
| Temperature | Humidity | Temperature/RH: 40°C/90% | | | |
| Operating Temperature | | -10 | 50 | °C | |

4. Module Cleaning Procedures

- 1. Avoid using any chemicals or water on the camera lens.
- 2. Use a lens blower brush to remove dust and dirt from the lens as thoroughly as

possible.

3. Wipe with a dry, clean microfiber cloth.

5, Disclaimer

The device application information and similar content provided in this publication are for your convenience only and may be replaced by updated information. It is your responsibility to ensure that the application complies with technical specifications. The company makes no express or implied, written or oral, statutory or other representations or warranties regarding this information, including but not limited to declarations or warranties of its use, quality, performance, merchantability, or fitness for a particular purpose. The company shall not be liable for any consequences arising from this information or its use. This product may not be used as a critical component in life support systems without the written approval of the company.

Appendix 1: Module Drawings



